

COMMAND CENTER- QUICK START GUIDE

-  **UP**
Light
-  **POWER**
On/Off
-  **DOWN**
WALK




- **PRESS POWER** to Start
NOTE eBike will not power on if charger is plugged into battery
- Toggle **UP & DOWN** to move through PAS & Features

CLASS 2		
Factory Pre-Set Settings		
PAS Level	Top Speed	CLASS 2 THROTTLE
5	20	20
4	16	16
3	12	12
2	8	8
1	5	5
0	Human Powered	
Walk Mode	2	

CLASS 2 THROTTLE Top speed is regulated at 20 mph and by PAS level you are in

See Command Center Guide for full details on functions, options & Rider Comfort Customization



PLEASE ALWAYS acknowledge LOCAL LAWS, WEAR A HELMET, RIDE SAFELY! DO NOT MAKE UNATHORIZED CHANGES, this VOIDS all WARRANTY
If you have any questions, please reach out to your local eBike store or The RIDE Bikes

